



Safety

Installation

General Use

F.A.Q.

Troubleshooting

Warranty

Appendix

Common Wire Connections

You may not need to make every accessory connection that you see outlined on the following pages. However, the steps shown on this page are generally the most common and should be read carefully.

IMPORTANT:

If you are in doubt about the mounting options or the connectivity at any stage of this installation, please contact an ASE representative for assistance. They will be able to guide you through your specific installation options more clearly.

Attach External Antennas

The 9575 Dock accepts a male TNC for Iridium and a male SMA for GPS.



IMPORTANT:

Do not exceed cable lengths outlined in the troubleshooting section of this manual. Keep cable splices to a minimum.

Attach & Lock Power Input Jack

Align the pin of the cord with the receptacle and press the plug firmly in place. Next twist the collar to "lock" the cord to the Docking Station.



IMPORTANT:

The lock collar on this cable should only be tightened "finger-tight." Do not use pliers as this will overtighten the cable and potential damage the connector housing.

Attach Mini USB (optional except for data connectivity)

Align the Mini USB plug by positioning the graphic icon toward yourself, and gently press it into the receptacle. The plug should give you a tactile "click" once it is fully inserted.





Safety

Installation

General Use

F.A.Q.

Troubleshooting

Warranty

Appendix

Optional Wire Connections

The steps on this page may not be applicable to every installation, and should be considered optional.

IMPORTANT:

If you are in doubt about the mounting options or the connectivity at any stage of this installation, please contact an ASE representative for assistance. They will be able to guide you through your specific installation options more clearly.

Attach Coded Privacy Handset (Included with Mounting Accessory Kit)

Connect your Coded Intelligent Handset to the RJ-45 jack as shown. The plug should be pressed into the socket until an audible 'click' is heard; this indicates the plug is fully seated and locked in position.

IMPORTANT:

Although this port uses a common RJ-45 connector, it will NOT support a connection to anything other than an Coded Intelligent Handset. Additionally, only one handset is supported.



Attach RJ-11 Analog Phone / PABX Interface (9575P Only)

Connect your telephone line to the RJ-11 jack as shown. The plug should be pressed into the socket until an audible 'click' is heard; this indicates the plug is fully seated and locked in position.

TO REMOVE:

Use your finger to squeeze the small plastic tab on the plug; this will "unlock" the plug thus allowing for its removal.

